

<table><tr><td>Outer shell</td><td>: Brass (UNS C38500)</td><td>Chrome plated (FS-QQ-C-320B)</td></tr><tr><td>Earthing crown</td><td>: Special brass</td><td>Nickel plated (FS-QQ-N-290A)</td></tr><tr><td>Collet nut</td><td>: Brass (UNS C38500)</td><td>Chrome plated (FS-QQ-C-320B)</td></tr><tr><td>Insulator</td><td>: PEEK</td><td>-</td></tr><tr><td>Female contact</td><td>: Bronze (UNS C54400)</td><td>Gold plated (ISO 27874)</td></tr><tr><td>Clip</td><td>: Stainless steel</td><td>-</td></tr><tr><td>Notched nut</td><td>: Brass (UNS C38500)</td><td>Chrome plated (FS-QQ-C-320B)</td></tr><tr><td>Gland</td><td>: Silicone (SI)</td><td>-</td></tr><tr><td>Retaining ring</td><td>: Stainless steel (AISI304L)</td><td>-</td></tr><tr><td>Other metallic parts</td><td>: Brass (UNS C38500)</td><td>Nickel plated (FS-QQ-N-290A)</td></tr><tr><td>O-rings</td><td>: Silicone (MVQ)</td><td>-</td></tr></table>		Outer shell	: Brass (UNS C38500)	Chrome plated (FS-QQ-C-320B)	Earthing crown	: Special brass	Nickel plated (FS-QQ-N-290A)	Collet nut	: Brass (UNS C38500)	Chrome plated (FS-QQ-C-320B)	Insulator	: PEEK	-	Female contact	: Bronze (UNS C54400)	Gold plated (ISO 27874)	Clip	: Stainless steel	-	Notched nut	: Brass (UNS C38500)	Chrome plated (FS-QQ-C-320B)	Gland	: Silicone (SI)	-	Retaining ring	: Stainless steel (AISI304L)	-	Other metallic parts	: Brass (UNS C38500)	Nickel plated (FS-QQ-N-290A)	O-rings	: Silicone (MVQ)	-
Outer shell	: Brass (UNS C38500)	Chrome plated (FS-QQ-C-320B)																																
Earthing crown	: Special brass	Nickel plated (FS-QQ-N-290A)																																
Collet nut	: Brass (UNS C38500)	Chrome plated (FS-QQ-C-320B)																																
Insulator	: PEEK	-																																
Female contact	: Bronze (UNS C54400)	Gold plated (ISO 27874)																																
Clip	: Stainless steel	-																																
Notched nut	: Brass (UNS C38500)	Chrome plated (FS-QQ-C-320B)																																
Gland	: Silicone (SI)	-																																
Retaining ring	: Stainless steel (AISI304L)	-																																
Other metallic parts	: Brass (UNS C38500)	Nickel plated (FS-QQ-N-290A)																																
O-rings	: Silicone (MVQ)	-																																
<table><tr><td></td><td><ol style="list-style-type: none"><li>Strip the cable according to the given dimensions . (The end of the cable jacket must be cut properly) . Slide it into the collet nut①, the collet②, the gland③and the earthing cone④.</li><li>In case of a screened cable , fold screen back over the extremity of the earthing cone . Fix the positioner on the crimping tool and set selector to the number corresponding to the conductor AWG as indicated on the positioner label . Fit conductor into the contacts⑤and make sure it is visible through its inspection hole in the crimp barrel . Open crimping tool then push contact fully into positioner and complete one crimping cycle . Remove from crimping tool and check that conductor is secure in contact and shows in inspection hole .</li><li>Slide contact-conductor combinations according to the insulator⑥marking avoiding twisting of the conductors . Fit the contacts gently into the insulator and verify that no conductors are crossed before pushing them in completely . Check that all contacts hold in the insulator by verifying their alignment at the front of the insulator and they should remain in position when each conductor is given a gentle pull . Check that retention of the contact is correct with the recommended test tool .</li><li>Locate the slotted upper half⑦of the split insert carrier over the shoulder and key on the insulator then align and press together the other half⑧to form a complete cylinder . Push the earthing cone against the insert carriers whilst checking that the screen is being clamped around the whole circumference and cut , if necessary , the excess screen . Push the gland , and collet against the earthing cone . Push the cable forward and verify that cable jacket is located under the gland .</li><li>Next slide the socket shell⑨over the insulator assembly making sure that the key on the insert carrier goes into the keyway (under the color point) inside the shell . Locate the key of the collet into the slot of the shell . Finally screw the collet nut with the appropriate tool and tighten to the maximum torque value of 2Nm .</li></ol></td></tr></table>			<ol style="list-style-type: none"><li>Strip the cable according to the given dimensions . (The end of the cable jacket must be cut properly) . Slide it into the collet nut①, the collet②, the gland③and the earthing cone④.</li><li>In case of a screened cable , fold screen back over the extremity of the earthing cone . Fix the positioner on the crimping tool and set selector to the number corresponding to the conductor AWG as indicated on the positioner label . Fit conductor into the contacts⑤and make sure it is visible through its inspection hole in the crimp barrel . Open crimping tool then push contact fully into positioner and complete one crimping cycle . Remove from crimping tool and check that conductor is secure in contact and shows in inspection hole .</li><li>Slide contact-conductor combinations according to the insulator⑥marking avoiding twisting of the conductors . Fit the contacts gently into the insulator and verify that no conductors are crossed before pushing them in completely . Check that all contacts hold in the insulator by verifying their alignment at the front of the insulator and they should remain in position when each conductor is given a gentle pull . Check that retention of the contact is correct with the recommended test tool .</li><li>Locate the slotted upper half⑦of the split insert carrier over the shoulder and key on the insulator then align and press together the other half⑧to form a complete cylinder . Push the earthing cone against the insert carriers whilst checking that the screen is being clamped around the whole circumference and cut , if necessary , the excess screen . Push the gland , and collet against the earthing cone . Push the cable forward and verify that cable jacket is located under the gland .</li><li>Next slide the socket shell⑨over the insulator assembly making sure that the key on the insert carrier goes into the keyway (under the color point) inside the shell . Locate the key of the collet into the slot of the shell . Finally screw the collet nut with the appropriate tool and tighten to the maximum torque value of 2Nm .</li></ol>																															
	<ol style="list-style-type: none"><li>Strip the cable according to the given dimensions . (The end of the cable jacket must be cut properly) . Slide it into the collet nut①, the collet②, the gland③and the earthing cone④.</li><li>In case of a screened cable , fold screen back over the extremity of the earthing cone . Fix the positioner on the crimping tool and set selector to the number corresponding to the conductor AWG as indicated on the positioner label . Fit conductor into the contacts⑤and make sure it is visible through its inspection hole in the crimp barrel . Open crimping tool then push contact fully into positioner and complete one crimping cycle . Remove from crimping tool and check that conductor is secure in contact and shows in inspection hole .</li><li>Slide contact-conductor combinations according to the insulator⑥marking avoiding twisting of the conductors . Fit the contacts gently into the insulator and verify that no conductors are crossed before pushing them in completely . Check that all contacts hold in the insulator by verifying their alignment at the front of the insulator and they should remain in position when each conductor is given a gentle pull . Check that retention of the contact is correct with the recommended test tool .</li><li>Locate the slotted upper half⑦of the split insert carrier over the shoulder and key on the insulator then align and press together the other half⑧to form a complete cylinder . Push the earthing cone against the insert carriers whilst checking that the screen is being clamped around the whole circumference and cut , if necessary , the excess screen . Push the gland , and collet against the earthing cone . Push the cable forward and verify that cable jacket is located under the gland .</li><li>Next slide the socket shell⑨over the insulator assembly making sure that the key on the insert carrier goes into the keyway (under the color point) inside the shell . Locate the key of the collet into the slot of the shell . Finally screw the collet nut with the appropriate tool and tighten to the maximum torque value of 2Nm .</li></ol>																																	
<table><tr><td>Panel cut-out</td><td></td></tr><tr><td colspan="2">Torque for mounting nut : 9 Nm</td></tr></table>	Panel cut-out		Torque for mounting nut : 9 Nm		<table><tr><td>Crimping tool</td><td>: DPC.91.701.V</td><td>Spanner for notched nut</td><td>: DCH.91.251.PA</td></tr><tr><td>Extractor</td><td>: DCF.91.070.2LT</td><td>Flat spanners set</td><td>: DCP.91.023.TN</td></tr><tr><td>Female contact</td><td>: EGG.2B.655.ZZM</td><td></td><td></td></tr><tr><td>Female positioner</td><td>: DCE.91.072.BVM</td><td></td><td></td></tr><tr><td>Female retention testing tool:</td><td>DCK.91.071.0LRM</td><td></td><td></td></tr></table>	Crimping tool	: DPC.91.701.V	Spanner for notched nut	: DCH.91.251.PA	Extractor	: DCF.91.070.2LT	Flat spanners set	: DCP.91.023.TN	Female contact	: EGG.2B.655.ZZM			Female positioner	: DCE.91.072.BVM			Female retention testing tool:	DCK.91.071.0LRM											
Panel cut-out																																		
Torque for mounting nut : 9 Nm																																		
Crimping tool	: DPC.91.701.V	Spanner for notched nut	: DCH.91.251.PA																															
Extractor	: DCF.91.070.2LT	Flat spanners set	: DCP.91.023.TN																															
Female contact	: EGG.2B.655.ZZM																																	
Female positioner	: DCE.91.072.BVM																																	
Female retention testing tool:	DCK.91.071.0LRM																																	
<table><tr><td rowspan="4">Straight socket with nut fixing , with key (G) , with antirotating cable collet and nut . (Back panel mounting) . Series 2K , multipole (12)</td><td>Echelle</td><td>Dessiné</td><td>02.10.2019</td><td>OVU / NHA</td></tr><tr><td>—</td><td>Contrôle</td><td>02.10.2019</td><td>NHA / ATVI</td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td>Modif.</td><td>00</td><td colspan="2">02.10.2019/ OVU</td></tr></table>		Straight socket with nut fixing , with key (G) , with antirotating cable collet and nut . (Back panel mounting) . Series 2K , multipole (12)	Echelle	Dessiné	02.10.2019	OVU / NHA	—	Contrôle	02.10.2019	NHA / ATVI					Modif.	00	02.10.2019/ OVU																	
Straight socket with nut fixing , with key (G) , with antirotating cable collet and nut . (Back panel mounting) . Series 2K , multipole (12)	Echelle		Dessiné	02.10.2019	OVU / NHA																													
	—		Contrôle	02.10.2019	NHA / ATVI																													
	Modif.	00	02.10.2019/ OVU																															
ETUDE N° E7077-E7114-E6041-E7176-E6387-E10636																																		
<table><tr><td></td><td>LEMO SA Chemin des Champs-Courbes 28 1024 Ecublens - SWITZERLAND</td><td>Tel. (+41 21) 695 16 00 email : <a href="mailto:info@lemo.com">info@lemo.com</a> <a href="http://www.lemo.com">www.lemo.com</a></td><td>PEG.2K.312.CYMC__</td></tr></table>			LEMO SA Chemin des Champs-Courbes 28 1024 Ecublens - SWITZERLAND	Tel. (+41 21) 695 16 00 email : <a href="mailto:info@lemo.com">info@lemo.com</a> <a href="http://www.lemo.com">www.lemo.com</a>	PEG.2K.312.CYMC__																													
	LEMO SA Chemin des Champs-Courbes 28 1024 Ecublens - SWITZERLAND	Tel. (+41 21) 695 16 00 email : <a href="mailto:info@lemo.com">info@lemo.com</a> <a href="http://www.lemo.com">www.lemo.com</a>	PEG.2K.312.CYMC__																															